



Fun Company FunGlo Cabinet Target Toss Pro: Bags Video and Audio Connections Guide


Target Toss Pro Bags support SVGA (800 x 600) resolutions, but will work on many HDTVs with a VGA input. Note that the display may be stretched to accommodate the widescreen format.

NOTE: Video and audio connections to these displays vary, and may require additional cables not included with the FunGlo cabinet. In addition, some displays may not support the resolution needed for your game. Check your display's manual for additional information

The FunGlo cabinet is shipped with a 15 foot VGA cable for use in connecting your HDTV or monitor.

Connect to VGA

Connect the supplied VGA adaptor to the DVI output on the Incredible Technologies computer. Connect a VGA cable to the DVI to VGA adaptor. Route the cable through the cord hole in the rear of the cabinet and connect the end of the VGA cable to the proper input on your television. Common input label names for VGA are RGB, Computer, or PC.




Set Up Your HDTV

Refer to the HDTV manual to adjust the video signal to match the correct input that your game is connected to. Selecting the correct input is commonly found from a system menu accessed from the remote, or an input select button on the HDTV.

Incredible Technologies Dip Switch Settings for HDTVs

Dip switch bank Sw201 on the I/O Board controls the video resolution for the main monitor. If a different resolution is necessary for your display, refer to the chart below for the proper setting.



Note: A reboot is required when changing resolutions.

Fun Company

900 Harvey Street • PO Box 559 • Necedah, WI 54646
Toll Free: 800-808-5554 • Fax: 608-565-5564 • Local/International: 608-565-5558
<http://www.funcomfg.com>




Fun Company FunGlo Cabinet Target Toss Pro: Bags Video and Audio Connections Guide

Connect to HDTV Speakers

Although your FunGlo cabinet is shipped with speakers in the cabinet, it is recommended that you connect the game to the speakers on your HDTV. First, connect one end of a 2-wire red/white audio cable (not supplied) to the Incredible Technologies system box. Route the cable through the cord hole in the rear of the cabinet and connect the other end of the 2-wire cable to the appropriate RCA connections on your HDTV.


Refer to the game manual to enter the System Setup Menus, and adjust the volume on the game to 80%. Then adjust the volume on the HDTV to suit your location.



Connecting to FunGlo Cabinet Speakers

If your HDTV does not have speakers or the sound quality is poor, connect your game to the internal speakers inside the cabinet. This is how the game is configured when leaving the factory. First, connect one end of the supplied 2-wire red/white audio cable to the Incredible Technologies computer. Connect the other end of the 2-wire cable to the appropriate RCA connections on the game's I/O Board.

Refer to the game manual to enter the System Setup Menus, and adjust the volume on the game to suit your location. Then adjust the volume on the HDTV to zero or mute.



Audio Cables

If you need additional cables or different cable lengths not included with the Showpiece cabinet, they are available from a variety of retail and Internet sources. Monoprice.com is an excellent resource and a good place to start.

[2 RCA Plug/2 RCA Plug M/M Cable - 12ft](#)

[3.5mm Stereo Plug/2 RCA Jack cable - 6 inches](#)

Fun Company

900 Harvey Street • PO Box 559 • Necedah, WI 54646

Toll Free: 800-808-5554 • Fax: 608-565-5564 • Local/International: 608-565-5558

<http://www.funcomfg.com>